



# LINCOLN WINDOWS

*Quality Windows & Patio Doors*

[Products](#)
[Owner's Manual](#)
[Architectural Info](#)
[Warranty](#)
[Dealer Locator](#)
[Contact Us](#)

## *Owner's Manual - Glass Cleaning*

### Recommendations:

When cleaning your windows both inside and out the following list of suggestions should be followed:

- Clean the glass as soon as dirt and debris become apparent.
- Start cleaning at the top of a particular wall or window and work your way down.
- A mild soap and water solution or a vinegar and water solution should be used with a soft cloth or sponge to remove dirt and debris.
- Use a squeegee or clean soft cloth with clean water, to remove the cleaning solution.
- With a separate cloth, wipe excess solution from the glass as well as the frame and surrounding materials.

### Additional precautions and warnings:

- Do not use power washers or garden hoses to clean windows.
- Do not use metal scrapers of any kind or allow metal parts of cleaning equipment to contact glass. The Lincoln Window or door warranties do not cover glass scratched by scrapers, razor blades, or tools.
- Do not use abrasive cleaners on the glass surface.
- Do not clean windows in direct sunlight.
- Do not allow cleaning solutions to dry on glass or surrounding surfaces.

### Screen Cleaning Recommendations:

To clean your screen of dust and light debris you may use the upholstery brush supplied with your vacuum cleaner. Heavier debris such as kitchen grease may be removed by gently scrubbing with mild soap and a soft brush. Screens should be rinsed to remove dirt and soap residue. Be sure that screens are dry before they are re-installed.

[Home](#) | [Contact Us](#) | [General Info](#) | [Dealer Locator](#) | [Warranties](#)

©2006 Lincoln Wood Products